

FloodKit® Toilet Stopper

The FloodKit® Toilet stopper is an effective tool for blocking any width or shape of toilet pan against sewage back flow either during a flood, or if work is being carried out on external pipes that are being jetted to remove blockages in the main sewer.

This patented product is manufactured from strong yet lightweight Aluminium tube with a unique spring loaded mechanism, and will protect against floodwater in excess of 3ft in height.

It is supplied with 2 FloodKit® U bend bags that are filled with a special 100% natural, absorbent powdered clay that will form a perfect mould of any shape of U bend when it is placed in your toilet pan



Instructions for fitting.

Remove the lid from one of the pails.

Using the disposable gloves provided, remove the Bag from the pail and squeeze into a sausage shape.



Place the bag into the throat of the U Bend, and use the white Strut with the plunger at the end to push firmly into place.

Please note that the dust from the bag is non toxic. Place the gloves into the pail and store for use when you remove the bag after the flood.

Position the blue Cross Bar under the rim of the pan so that it lines up with the centre of the bag as follows.



Stand at the side of toilet holding the wider tube with the longer narrow tube pointing towards you, carefully place the black end of the narrow tube under the rim of the pan closest to you, ensuring that the angled end fits securely under the rim. Pull back on the wider tube and slide the other end of the bar under the rim on the other side. The springs will adjust to your toilet's pan width and hold the bar in position.

It is very important that you adjust the black plastic lug on the white strut to fit your toilet, this is very simple to do but is very important.



**A VIDEO OF THESE INSTRUCTIONS IS AVAILABLE TO VIEW ON-LINE
www.floodkit.co.uk**

Loosen the hand wheel so that the lug can move up and down the strut, place the strut so that the plunger is sitting on the centre of the bag and the bottom of the block at the base of the lug is



resting on top of the Blue bar, loosely tighten the hand wheel. Lift the strut and firmly tighten the hand wheel to fix the lug in position.

The strut is now calibrated and ready for use

This process should be followed each time you use your Toilet Stopper.



Place the white FloodKit® Toilet Strut so that the plunger head is close to the centre of the bag, just behind the Blue cross bar with the hand wheel facing the cistern. Push down on the strut and turn 90 degrees clockwise so that the lug locks into position under the cross bar

Removal

After the floodwaters have receded you can remove your FloodKit® Toilet Stopper by pushing down on the strut, turning it 90° anti clockwise to release the lug and removing the strut from the pan.

To remove the cross bar stand at the side of your toilet, with the narrower tube closest to you, grip the wider tube and pull the bar towards you and lift out.

Using the disposable gloves you can lift the bag out of the pan. Place the bag into the pail to allow for easy disposal. The bag can be placed into your household waste whilst the pail can be recycled. Any residual dust from the bag can be cleaned from the pan with a toilet brush and flushed away.



The plunger can now be cleaned and dried, take care not to immerse the Cross bar and Strut in water.

The Strut with the plastic lug and plunger along with the Cross Bar can be re used whilst replacement FloodKit® U-Bend Bags are available from www.floodkit.co.uk/shop and other retailers.