

Concrete Fixing Kit For Speed Bumps

Materials:

Supplied in pairs:
Zinc Plated Steel Bolt &
Shield



Left – Assembled
Right – Unassembled

Instructions For Use:

1. Position required number of speed bumps and mark the location of the fixing holes on the surface to be applied to.
2. Remove speed bumps and drill holes at the marked positions as follows: Concrete – 20mm Diameter Hole Size, Minimum Depth 65mm. The correct fixing for the surface must be used.
3. Clean hole of debris.
4. Insert bolt shield into hole.
5. Reposition units and pass the bolts through the locating holes and screw into the shield.
6. Tighten bolt to a torque of: 27NM.

It is the responsibility of the Landowner / Leaseholder to place appropriate signage to indicate the speed limit at which the Speed Bumps should be approached.

Limitations Of Use:

Damage to vehicle components is possible if the speed bumps are approached at speeds higher than recommended.