# The Skipper unit



Tape end clip This attaches to the next Skipper unit or accessory



Locking button For use in windy conditions Stops unwanted spooling of

tape (tape will still retract). Tape slot

These are the receptors for tape end clips from other Skipper units.







**INCORRECT USE** 

DO NOT allow the tape

DO NOT retract or pull tape

with lock on. This will cause

premature unit failure

DO NOT immerse the unit



Using your Skipper units Avoid damage, improve lifespan and get the most out of the total safety management solution.

CORRECT USE

Click the Skipper unit on

top of the cone or post





an object and attach to itself

**FEATURES** 

Use the clip to attach

to other Skipper units or

accessories



More products from Skipper



This revolutionary two-piece cone includes an incorporated helix which deflects wind and adds to stability. It can also facilitate an optional weight ring, and its glass bead sleeve has greater reflectivity than other cones.







Then pull out the tape from the next unit

Each Skipper unit has

Use screw fitting for

permanent fixture

multi-point connectivity

## Skipper post & base system >

The Skipper Post's great versatility allows it to be used on both hard and soft ground, indoors and outdoors. The unique, interchangeable base allows it to be sunk into the ground with a spike or attached to its sturdy base for use on hard surfaces.

> Call Aspli Safety Ltd 0113 2461 550



### IMPORTANT NOTICE

Tape may be prone to fading if left in direct sunlight for very long periods. To maximise unit life it is VERY IMPORTANT to observe the guidelines above. Failure to do so could seriously

affect the performance of the Skipper unit and risk invalidating the guarantee.